

MAKE / CONSTRUCTEUR	MODEL / MODÈLE	MODEL REFERENCE / RÉFÉRENCE	POSITIONING COORDINATES / POSITION
Samsung	Galaxy S3 mini	GT-I8190	H5 - A7 - D7
Samsung	Galaxy S4	GT-I9505	G3 - A9 - D3
Samsung	Galaxy S4 mini	GT-I9195	H5 - B10 - E6
Samsung	Galaxy S5	SM-G900F	H3 - A9 - E3
Samsung	Galaxy S5 mini	SM-G800F	I2 - B10 - E5
Samsung	Galaxy S6	SM-G920F	I2 - C9 - D3
Samsung	Galaxy S6 Edge	SM-G925F	G2 - A6 - F6
Samsung	Galaxy S6 Edge +	SM-G928F	G2 - A5 - D5
Samsung	Galaxy S7	SM-G930F	I2 - A6 - D6
Samsung	Galaxy S7 Edge	SM-G935F	I2 - C6 - E6
Samsung	Galaxy S8	SM-G950F	I2 - C9 - F4
Samsung	Galaxy S8+	SM-G955F	I2 - C9 - D2
Samsung	Galaxy S9	SM-G960F/DS	I2 - B8 - D5
Samsung	Galaxy S9+	SM-G965F/DS	H2 - C9 - D2
Samsung	Galaxy S10	SM-G973F	H2 - B10 - E3
Samsung	Galaxy S10e	SM-G970F	H2 - A9 - F3
Samsung	Galaxy S10 Plus	SM-G975F	I2 - A9 - F2
Samsung	Galaxy Trend / Trend Lite	GT-S7560 / GT-S7390G	I3 - C9 - F6
Samsung	Galaxy Trend 2 / Trend 2 Lite	SM-G313HN / SM-G318H	H3 - C6 - F9
Samsung	Galaxy Y	GT-S5360/69	H2 - A8 - D8
Samsung	Galaxy Young	GT-S6310	I2 - A8 - D8
Sony	Xperia E5	F3311	I4 - B10 - F3
Sony	Xperia M2	D2303	H2 - B6 - D6
Sony	Xperia M4 Aqua	E2303	I3 - B6 - F6
Sony	Xperia M5	E5603	I3 - A9 - F3
Sony	Xperia SP	C5303	I2 - C7 - F7
Sony	Xperia XA1	G3121	G2 - B7 - E7
Sony	Xperia XA1 Ultra	G3221	H3 - B7 - E3
Sony	Xperia Z3	D6603	H3 - A9 - E3
Sony	Xperia Z3 compact	D5803	H1 - C7 - F7
Sony	Xperia Z5	E6653	I2 - A9 - D2
Sony	Xperia Z5 compact	E5823	G2 - A9 - F5
Wiko	Goa	-	I2 - B8 - E8
Wiko	Lenny	-	G3 - B10 - E2
Wiko	Lenny 3	-	H3 - B10 - E2
Wiko	Ozzy	-	I4 - B8 - E8
Wiko	Sunny	-	G4 - C7 - F7
Wiko	Sunset	-	H4 - C7 - F7
Wiko	Sunset 2	-	G4 - C7 - F7
Xiaomi	RedMi Note 3	-	H3 - C1 - E10
Xiaomi	RedMi Note 5	-	G2 - B8 - F3
Xiaomi	RedMi Note 6 Pro	M1806E7TG	I2 - A9 - F1
Xiaomi	RedMi Note 7	M1901F7G	G1 - C9 - E2
Xiaomi	Mi 9	M1902F1G	H2 - A9 - E2

A few examples of how to position Fazup.

The Fazup passive antenna is positioned specifically, depending on the model of your smartphone. The Fazup antenna can be centered, off-centre or it may even follow the shape of the edge of the smartphone. Check out how Fazup should look when applied on your specific smartphone model at www.fazup.com/pose.

Quelques exemples de position de Fazup.

Le patch Fazup se positionne différemment en fonction des modèles de mobiles. Le patch peut être centré, excentré ou même épouser la courbure du mobile. Voir la photo de votre mobile avec Fazup: www.fazup.com/pose.

In order to guarantee Fazup's maximum lifespan, it is highly recommended to use a protective case. / Utilisez une coque de protection pour protéger l'antenne Fazup de l'usure.




In most cases, the partial protective case does not cover the edge of the iPhone. Therefore, it doesn't protect the edge of the patch when it goes over the curved edge of the smartphone.

Coque ne couvrant pas la tranche de l'iPhone. Ne protégez pas l'extrémité du patch dans la courbure.

How to find the model reference of your phone.

> Find it in "settings" menu of your mobile phone.

> Reboot your mobile, on some brands the welcome screen provides the model reference (Samsung for example).



iPhoneX

Sony Xperia Z3 Compact



Samsung J7 2017

Samsung Galaxy S6

FAZUP



POSITIONING Guide Guide des POSITIONS

This positioning guide helps you to configure the positioning tool, in order to place Fazup in the most efficient position on the back of your mobile.

- 1 - Find your smartphone model in the list of compatible phones
- 2 - Based on the corresponding positioning code, create your positioning tool and place Fazup with maximum efficiency.

Cet guide vous permet de configurer votre positionneur afin de coller Fazup précisément au dos de votre mobile.

- 1 - Il vous suffit d'identifier votre modèle de mobile dans la liste suivante
- 2 - À partir de coordonnées de positionnement correspondantes, créez votre gabarit de pose en suivant les instructions de la notice.



The full-body protective case covers the edge of the iPhone, protecting the edge of the patch when it goes over the curved edge of the smartphone.

Coque couvrant la tranche de l'iPhone. Protège l'extrémité du patch dans la courbure.

Comment trouver la référence du modèle de votre mobile.

> Regardez dans le menu "Paramètres" de votre mobile.

> Redémarrez votre mobile, sur certaines marques l'écran d'accueil affiche la référence du mobile (Samsung par exemple).

See the User guide for step-by-step positioning instructions/
Suivez les instructions de positionnement dans la Notice

IMPORTANT: If your mobile model is not listed here, check for the updated list at www.fazup.com/ **IMPORTANT:** Si votre modèle de mobile n'est pas répertorié dans ce document, consultez la liste mise à jour sur www.fazup.com

MAKE / CONSTRUCTEUR	MODEL / MODÈLE	MODEL REFERENCE / RÉFÉRENCE	POSITIONING COORDINATES / POSITION
Apple	iPhone 3G	A1241	G6 - B8 - E8
Apple	iPhone 3GS	A1303	H8 - B8 - E8
Apple	iPhone 4 / 4S	A1332 / A1387	G2 - C8 - F8
Apple	iPhone 5 / 5C / 5S / SE	A1429 / A1507 / A1457 / A1723	I2 - C8 - F8
Apple	iPhone 6 / 6S / 7	A1586 / A1688 / A1778	G1- B4 - E10
Apple	iPhone 6+ / 6S+ / 7+ / 8 +	A1524 / A1687 / A1784 / A1897	G1 - A1 - E9
Apple	iPhone 8	A1905	H2 - C9 - D4
Apple	iPhone X/XS	-	G1 - B3 - E10
Apple	iPhone XS Max	-	G1 - A1 - E9
Apple	iPhone XR	-	G1 - A1 - D9
Asus	Zenfone 3	ZE520KL	G1 - B10 - E2
Asus	Zenfone 3 Max	ZC520TL	I2 - B10 - E2
Asus	Zenfone 4 Max	ZC520KL	G4 - C2 - E10
BlackBerry	Bold 9900	-	H6 - C7 - F7
BlackBerry	Classic	Q20	H2 - B6 - D6
BlackBerry	Curve 9320	-	I3 - B8 - E8
BlackBerry	Curve 9720	-	H6 - C7 - F7
BlackBerry	Passport	-	G2 - C3 - F3
BlackBerry	Q5	-	H3 - C7 - F7
BlackBerry	Z10	-	G2 - C7 - F7
Google	Pixel 3	G013A	H2 - A3 - E10
Google	Pixel 3 XL	G013C	H2 - B1 - D9
Huawei	Ascend G620S	G620S-L01	G3 - B5 - D7
Huawei	GT3	NMO-L02	I2 - B2 - E10
Huawei	Honor 5C	-	I2 - B2 - E10
Huawei	Honor 5X	-	H2 - B10 - E1
Huawei	Honor 6x	BLN-L21	I2 - B1 - E10
Huawei	Honor 7	PLK-L01	G1 - C2 - E10
Huawei	Honor 7 Lite	-	I2 - B2 - E10
Huawei	Honor 7X	BND-L21	G3 - B8 - F3
Huawei	Honor 8	FRD-L09	H2 - A9 - D3
Huawei	Honor 8X	JSN-L21	G1 - B9 - E2
Huawei	Honor 9	STF-L09	I2 - C6 - F6
Huawei	Honor 9 Lite	LLD-L31	H3 - C3 - E9
Huawei	Honor 10	COL-L29	G2 - C2 - E10
Huawei	Honor 10 Lite	HRY-LX1	H2 - B10 - E2
Huawei	Honor View 10	BKL-L09	I2 - A9 - E2
Huawei	Honor View 20	PCT-L29	H2 - B7 - F4
Huawei	Mate 9	MHA-L29	I2 - B5 - E5
Huawei	Mate 10 Pro	BLA-L29	H2 - B10 - E2
Huawei	Mate 20	HMA-L29	I2 - A9 - E1
Huawei	Mate 20 Pro	LYA-L29	I2 - B10 - F2

MAKE / CONSTRUCTEUR	MODEL / MODÈLE	MODEL REFERENCE / RÉFÉRENCE	POSITIONING COORDINATES / POSITION
Huawei	Nova 2	PIC-LX9	I2 - C8 - F5
Huawei	P7	-	G1 - A3 - E10
Huawei	P8	GRA-L09	I3 - C6 - F6
Huawei	P8 Lite	ALE-L21	H3 - B3 - E10
Huawei	P8 Lite 2017	PRA-LX1	I3 - C2 - D9
Huawei	P9	EVA-L09	I3 - B10 - E3
Huawei	P9 Lite	VNS-L31	H2 - B6 - F6
Huawei	P10	VTR-L09	I2 - A6 - D6
Huawei	P10 Lite	WAS-LX1A	G1 - B10 - D2
Huawei	P20	EML-L29	G1 - B10 - E3
Huawei	P20 Lite	ANE-LX1	H2 - B10 - E3
Huawei	P20 Pro	CLT-L29	G1 - B10 - E2
Huawei	P30	ELE-L29	H2 - B5 - D7
Huawei	P30 Pro	VOG-L29	H2 - B6 - E6
Huawei	P Smart 2018	FIG-LX1	H3 - C6 - F6
Huawei	P Smart 2019	POT-LX1	I2 - B10 - E2
Huawei	Y5 II	-	I2 - A2 - E10
Huawei	Y5 2018	DRA-L21	G3 - C3 - D9
Huawei	Y6 2017	MYA-L41	G1 - B10 - F2
Huawei	Y6 2018	ATU-L21	G2 - B10 - F2
Huawei	Y7 2019	DUB-LX1	G1 - B10 - E1
LG	G2	P15661	G2 - C6 - F6
LG	G3	-	G2 - A1 - E10
LG	G6	-	G1 - B10 - F2
LG	Nexus 4	E960	I4 - C6 - F7
LG	Nexus 5	D820	I2 - A6 - D6
LG	Optimus 2X	P990	H3 - A7 - D7
Motorola	Moto G	1st generation	I2 - C7 - F7
Motorola	Moto G	3rd generation XT1541	G2 - A2 - E10
Motorola	Razr	-	I3 - A6 - D6
Nokia/Microsoft	3310 3G	-	G3 - B10 - E10
Nokia/Microsoft	Lumia 635	-	G2 - A9 - E5
Nokia/Microsoft	Lumia 650	RM-1152	G1 - B3 - E10
Nokia/Microsoft	Lumia 830	-	H2 - C9 - D3
Nokia/Microsoft	Lumia 920	-	I2 - C5 - D7
Oneplus	Oneplus 3	A3003	H4 - B4 - D7
Oneplus	Oneplus 5 / 5T	-	I2 - A2 - E9
Oneplus	Oneplus 6	A6003	H2 - B2 - F9
Oppo	RX17 Pro	CPH1877	H2 - B9 - D2
Pocophone	F1	M1805E10A	G1 - C1 - E10
Samsung	Galaxy A3 2015 / 2016	SM-A300FU / SM-A310F	G2 - B10 - F4
Samsung	Galaxy A3 2017	SM-A320FL	I2 - B10 - F4
Samsung	Galaxy A5 2015	SM-A500FU	I2 - B10 - D3
Samsung	Galaxy A5 2016 / 2017	SM-A510F / SM-A520F	G2 - B10 - D2
Samsung	Galaxy A6 2018	SM-A600FN	I4 - C8 - F4

MAKE / CONSTRUCTEUR	MODEL / MODÈLE	MODEL REFERENCE / RÉFÉRENCE	POSITIONING COORDINATES / POSITION
Samsung	Galaxy A7 2015	SM-A700F	I2 - B10 - F1
Samsung	Galaxy A7 2016	SM-A710F	I2 - A1 - E10
Samsung	Galaxy A7 2018	SM-A750FN	H2 - C8 - D2
Samsung	Galaxy A8 2018	SM-A530F	H2 - C9 - D3
Samsung	Galaxy A40	SM-A405FN	H2 - A9 - E4
Samsung	Galaxy A50	SM-A505FN	H2 - A9 - E2
Samsung	Galaxy A70	SM-A705FN	I2 - B10 - E1
Samsung	Galaxy Ace 1	GT-S5830	I3 - C8 - F8
Samsung	Galaxy Ace 2	GT-I8160P	H2 - C6 - F9
Samsung	Galaxy Ace 3	GT-S7275R	H5 - C6 - F9
Samsung	Galaxy Ace 4	SM-G357FZ	H5 - C7 - F7
Samsung	Galaxy Alpha	SM-G850F	I2 - C7 - F7
Samsung	Galaxy Core	GT-I8260	I5 - C9 - D4
Samsung	Galaxy Core 2	SM-G355HN	H3 - A8 - E5
Samsung	Galaxy Core 4G	SM-G386F	H4 - C7 - E7
Samsung	Galaxy Core Plus	SM-G350	I4 - C7 - F7
Samsung	Galaxy Core Prime	SM-G360F	I3 - C9 - F4
Samsung	Galaxy Express	GT-I8730	H5 - A3 - E10
Samsung	Galaxy Express 2	SM-G3815	I2 - A4 - E10
Samsung	Galaxy Fame	GT-S6810	H3 - B10 - F6
Samsung	Galaxy Grand 2	SM-G7105	H4 - B2 - F9
Samsung	Galaxy Grand Plus	GT-I9060i	G4 - B1 - D9
Samsung	Galaxy Grand Prime	SM-G530	G4 - B9 - D3
Samsung	Galaxy J1 2015	SM-J100H	I5 - A6 - E7
Samsung	Galaxy J1 2016	SM-J120H	I3 - A6 - E7
Samsung	Galaxy J2 2015	SM-J200H	G2 - B10 - D3
Samsung	Galaxy J3 2016	SM-J320FN	G4 - A8 - E4
Samsung	Galaxy J3 2017	SM-J330FN	I2 - C7 - D5
Samsung	Galaxy J4 Plus (2019)	SM-J415FN	H3 - B9 - D1
Samsung	Galaxy J5 2015	SM-J500FN	H3 - B6 - F6
Samsung	Galaxy J5 2016	SM-J510FN	G1 - B10 - D2
Samsung	Galaxy J5 2017	SM-J530F	G4 - A9 - E3
Samsung	Galaxy J6 2018	SM-J600FN	H3 - C9 - D3
Samsung	Galaxy J6+ 2018	SM-J610FN	H3 - C9 - D1
Samsung	Galaxy J7 2015	SM-J700H	H4 - A7 - D2
Samsung	Galaxy J7 2016	SM-J710FN	G1 - B10 - E1
Samsung	Galaxy J7 2017	SM-J730F	I4 - A9 - D1
Samsung	Galaxy Note 2	GT-N7100	I3 - B9 - E1
Samsung	Galaxy Note 3	SM-N9005	I4 - C9 - E1
Samsung	Galaxy Note 4	SM-N910F	I2 - B8 - F2
Samsung	Galaxy Note 5	SM-N920F	G2 - A5 - D5
Samsung	Galaxy Note 8	SM-N950F	G1 - B9 - D2
Samsung	Galaxy Note 9	SM-N960F	H2 - B10 - E1
Samsung	Galaxy Note Edge	SM-N915FY	G1 - B8 - E1
Samsung	Galaxy S	GT-I9000	G3 - A7 - D7
Samsung	Galaxy S2	GT-I9100	I3 - C7 - F7
Samsung	Galaxy S3	GT-I9300	H3 - B9 - E4